



Efficient very-large-mode-area thulium doped fibre laser for 2 μm operation

- Stacks of mid-IR laser sources
- Previous achievements
- Synthesis of a VLMA Tm-doped fibre
- Laser results and prospects




Dia Darwich, Romain Dauliat, Mostafa Sabra, Baptiste Leconte, Raphaël Jamier, Jean-Louis Auguste, Anka Schwuchow, Kay Schuster, Eric Lallier, and Philippe Roy





Université
de Limoges



Stakes of mid-IR sources



Current technology: CO₂ and quantum cascade laser



Route to mid-IR sources

STRATEGIES

- Monochromatic laser sources at 2 μm = Eye-safe wavelength range



Climatology / LIDAR




Ophthalmology


Host matrices

$\text{Tm}_2\text{O}_3:\text{SiO}_2$
 $\text{Ho}_2\text{O}_3:\text{SiO}_2$
 $\text{Tm}_2\text{O}_3:\text{Ho}_2\text{O}_3:\text{SiO}_2$
Er:ZBLAN

- High peak power for frequency conversion to mid-IR



Mid-IR supercontinuum



Terahertz waves



=> Next talk

2 μm fibre laser

CHALLENGES

- Moderate efficiency compared to Yb-doped laser

=> Need to favour the cross-relaxation mechanism





=> Efficiency can be as high as 80%

Defining an adequate material composition

GLASS MATRIX

- Host matrix: Aluminosilicate for solubility of Re_2O_3
- Tm_2O_3 introduced in large amount to favour ions proximity and cross relaxation
- $\text{Al}_2\text{O}_3:\text{Tm}_2\text{O}_3 \leftrightarrow 10:1 \Rightarrow$ Risk of phase separation




Material validation

FABRICATION OF STEP-INDEX FIBRES

- 1st composition of interest

Fibre n°493

0.3 mol % Tm_2O_3
3 mol % Al_2O_3






Core dimensions: 7*9 μm
Clad dimensions: 122*146 μm

D-shape
=
Improves pump absorption

Fibre lasers

DETERMINATION OF THE LASER EFFICIENCY

- Fibre 493: $\sim 9 \mu\text{m}$ core / $122 \times 146 \mu\text{m}$ clad – 5 dB/m abs. @ 792 nm




Material validation

FABRICATION OF STEP-INDEX FIBRES

- 2nd composition of interest

Fibre n°985

0.3 mol % Tm_2O_3
6 mol % Al_2O_3



Core dimensions: 18 μm
Clad dimensions: 221*289 μm


D-shape
=
Improves pump absorption

Part of this work, achieved by Dia Darwich, has been supported by a STSM in April 2016

Fibre lasers

DETERMINATION OF THE LASER EFFICIENCY




- Fibre 985: $\sim 18 \mu\text{m}$ core / $221 \times 286 \mu\text{m}$ clad



Fibre lasers

DETERMINATION OF THE LASER EFFICIENCY

- Fibre 985: $\sim 18 \mu\text{m}$ core / $221 \times 286 \mu\text{m}$ clad



Towards VLMA fibres

CHALLENGE


- Producing a singlemode VLMA fibre
- CVD techniques offers a limited control over the refractive index and so on the core size
- Our proposition: Repusil + Cladding-reduced Fully Aperiodic LPF

Repusil synthesis technique



Langner et al., PW (2012)
Schuster et al. Adv. Opt. Techn. 3(4)(2014)

Fully-Aperiodic Large-Pitch-Fibre



- An index matching between the active core and the passive cladding is mandatory

Synthesis and fibre fabrication


MATERIALS

- Core material: 0.3 mol% Tm_2O_3 + 3 mol% Al_2O_3
- Clad material: 3.7 mol% Al_2O_3

Stack



Microstructured cane



Rod-type FA-LPF




Control of the index matching



PROTOCOL

- Drawing of a « test fibre »
- Mapping the refractive index mapping using a commercial IFA device
- Performing a statistical analysis for improving the measurement accuracy

« Test fibre »




Refractive index mapping



$$\Delta n \sim 30 \cdot 10^{-5}$$



Tm-doped FA-LPF for 2 μm operation

LASER SETUP





Tm-doped FA-LPF for 2 μm operation

LASER RESULTS



Tm-doped FA-LPF for 2 μm operation



Thulium concentration	0,415mol% Tm_2O_3	0,3mol% Tm_2O_3
Core diameter (μm)	81	40 / 48
MFD (μm)	60	35 / 40
Efficiency (%)	33	31 / 36,5
M^2	< 1,5	< 1,45 / ??

F. Jansen et al. Opt. Lett., 37(21), 2012



Conclusions & Prospects

CONCLUSIONS

- Study of glasses composition for maximizing the cross relaxation
- Step index fibres: efficiency reaching up to 50%
- Influence of the temperature on the efficiency confirmed
- Fabrication of the first Tm-doped FA-LPF satisfactory

PROSPECTS

- Drawing fibres with larger dimensions
- Building a Q-switch laser
- Use this fibre as amplifier for Terahertz generation



Acknowledgements

Authors would like to thanks the COST MP 1401 for funding the STSM of Dia DARWICH in order to fabricate the material at IPHT in April 2016

Acknowledgement for:

Birgit Müller & Stephan Grimm: Preparation of raw materials,
Claudia Aichele: Tubes adjustment,
Matthias Arnz: Preform polishing & sample preparation,
Wolfgang Ludwig: Preform preparation for drawing, ...
Jörg Bierlich, Jens Kobelke & Anne Ludwig: Fiber drawing,
Martin Lorenz / Adrian Lorenz: Accurate refractive index measurements